Guardian

ACOUSTIC WALL PANEL



Oak



Maple



Walnut



Light Grey



Ebony

SIZE: 60 × 240 cm

Noise Reduction

Easy to Install

Lightweight

Three-Sided Coating

Step-by-step Guide

1 Preparation

- Clean the walls: Make sure the wall surface is clean, dry, and free of dust or debris. This ensures better adhesion.
- Measure the wall: Measure the area where you plan to install the panels to determine the layout and how many panels you'll need.
- Mark the layout: Use a pencil and level to mark the placement of each panel on the wall. This will help you position the panels correctly.

2 Cutting panels (if required)

- Measure and mark: Measure the panels and mark where they need to be cut.
- Cut the panels: Use a utility knife or saw to cut the panels to the desired size. Be sure to cut on a stable surface and wear safety gear.

3 Applying adhesive

- Load the caulk gun: Insert the construction adhesive into the caulk gun.
- Apply adhesive: Apply a generous amount of adhesive to the back of the acoustic panel. Create a zigzag pattern or apply dots of adhesive around the edges and centre of the panel.

4 Placing the panels

- Position the panel: Carefully place the panel onto the wall according to your layout marks.
- Press firmly: Press the panel firmly against the wall to ensure good adhesion. Hold it in place for a minute or so to allow the adhesive to bond.

5 Securing with screws

- Mark screw locations: Mark the locations where you will insert screws. Aim for corners and the centre of the panel.
- Drill pilot holes: If you're installing on drywall or a similar surface, drill pilot holes for the screws.
- Insert screws: Insert screws through the panel into the wall. If you're using anchors, insert them first, then screw into the anchors.
- Tighten screws: Ensure the screws are tight but not so tight that they deform the panel.

6 Finishing touches

- Clean up: Wipe off any excess adhesive that may have squeezed out from behind the panels.

Useful tips



- Work with a partner
  It's easier to position and secure panels accurately with two people.
- Check for level
  Use a level frequently to ensure panels are straight.
- Test adhesive first
  Test the adhesive on a small section to make sure it holds well before proceeding with the entire installation.

By following these steps, you should be able to install your acoustic panelling effectively.

Good luck with your project!